



ALL TILE POOL

Start-Up Instructions

Congratulations on your purchase of the longest lasting interior pool surface available today. The tile, whether it is glass or ceramic, is completely inert and impervious to chemical fluctuations in the water. In addition, we use epoxy grouts which have similar hydrophobic properties to insure an impenetrable barrier throughout the pool and/or spa interior.

We ask that you wait at least 7 days after the completion of the work before you start a hose to fill the pool to allow time for the grout to fully cure. It is also important that you fill continuously without stopping. Once the pool and/or spa are filled, start the pool equipment. Test the pool water and adjust the pH to 7.4 to 7.6, the total alkalinity to 100 to 120 ppm, and the calcium hardness to at least 250 ppm. Your chlorine residual should always be kept at 1.0 to 1.5 ppm to prevent algae growth. There is no need to brush the pool other than for regular maintenance and the pool sweep can be installed right away.

Feel free to call our office or talk to your field superintendent if you have any questions.

Any Questions? Call Us Toll Free 800-675-0665

www.AdamsPools.com